



Brake Bleeder Adapter Application Chart

BMW	All	BA05		
CADILLAC	32V Northstar 1996-	BA04		328 GTS BA05
	Eldorado TC 1996-	BA04		F40 BA05
	Seville SLS 1996-	BA04		Mondial T + convertable top BA05
	Seville STS 1996-	BA04		Testarossa BA05
	SRX 2003-	BA04		
	CTS (DOT3) 2001-	BA04		FIAT Most BA05
	XLR 2003-	BA04		
	BLS 2005-	BA05		FORD All older 2 tab models BA02
CHEVROLET	Alero 1999-	BA04		Cougar 1999- BA05
	Astro-Van 1996-	BA12		Courier 1995- BA05
	Blazer 1996-	BA04		Escort 1996- BA05
	Blazer 1999-	BA04		Explorer BA03
	Camaro 1999-	BA04		Fiesta 1996- BA05
	Corvette 1996-	BA04		Focus BA05
	Hummer H2 + H3 2003-	BA04		Fusion BA05
	S10 Pick-Up 2WD + 4WD 1996-	BA04		Galaxy 1995- BA05
	Suburban 1996-	BA12		Galaxy 2003- BA05
	Tahoe 1996-2002	BA12		Maverick + Ranger 1996- BA03
	Tahoe 2003-	BA04		Navigator (USA) 2001- BA03
Trans Sport 1999-	BA04		Probe -1992 BA03	
Trail Blazer 2001-	BA04		Probe 1993- BA05	
			Ranger 1999- BA05	
			Transit Van 1998- BA05	
			Windstar 1996- BA03	
CHRYSLER	Crossfire 2003-	BA05		GM All BA04
	300M 2.7 Executive 1999-	BA03		HONDA Civic/Accord/Prelude 1976-83 BA08
	300C Touring + Sedan 2005-	BA01		Accord 1985-1992 BA09
	Neon Sport 16V 1996-	BA03		Accord 1996- BA09
	Neon LE 1,6 2001-	BA01		Accord 1999- BA09
	New Yorker	BA03		Civi Shuttle BA07
	PT Cruiser 2001-	BA01		Civic 1992- BA08
	Sebring 2001-	BA03		Civic 1996- BA09
	Stratus 1999-	BA03		Civic (EJ 9) 1999- BA09
	Vision	BA04		CRX 1,6 BA07
	Viper 2003-	BA01		CRX 1,6 1997- BA09
	Grand Voyager 1999-	BA03		HR-V 1999- BA09
	Grand Voyager 2002	BA01		Insight 1999- BA09
	Voyager LE 1996 -	BA01		Legend 1991- BA09
	Voyager SE 1994-	BA01		Logo 1999- BA09
	Voyager SE 2,4 2001-	BA01		NSX-T (1981- =DOT3) 1999- BA08
	Voyager LX 2,5 2001-	BA01		Odyssey (US-Minivan) 1999- BA09
DAEWOO	Aveo 2005-	BA05		Prelude 1991- BA08
	Espero	BA05		Prelude 1992- BA09
	Evanda 2003-	BA04		Prelude 2,0 BA07
	Kalos 2003-	BA05		S 2000 1999- BA09
	Lacetti 2003-	BA05		Shuttle 1997- BA08
	Lanos	BA05		HYUNDAI All BA03
	Nexia	BA05		ISUZU Frontera 1989- BA08
	Nubira 1999-	BA05		Monterey 1989- BA08
	Nubira 2001-	BA04		Rodeo 2005- BA08
	Nubira WTCC R+ 2005-	BA05		Trooper -1989 BA07
DAIHATSU	Charmant 1989-	BA07		Trooper 1989- BA08
	Copen 2003-	BA08		JAGUAR Jaguar XJ Twin TD 2005- BA05
	Cuore / Charade -1989	BA07		Jaguar XKR 1999- BA05
	Cuore (L701) 1999-	BA08		Jaguar XJR 1999- BA05
	Cuore (L251) 2005-	BA08		Jaguar Sovereign 4.0 BA05
	Move (L901)	BA07		Jaguar S-Type V8 1999- BA03
	Gran Move (G301)	BA07		Jaguar S-Type R 2003- BA05
	Sirion (M100; M101)	BA07		Jaguar X-Type 2001- BA05
	Sirion (100,M101,M111) 2003-	BA08		Jaguar Daimler Super V8 BA05
	Terios (J102)	BA10		JEEP Jeep Cherokee 1995 BA03
YRV (M201)	BA07		Jeep Cherokee 1996- BA01	
FERRARI	Alle Pkw	BA05		Jeep Wrangler 1996- BA01
	328 GTB	BA05		Jeep Wrangler Sport 1999- BA01



Brake Bleeder Adapter Application Chart

	Jeep Wrangler 2003-	BA01	ROVER	All	BA03
	Jeep Grand Cherokee 1996-	BA01	SAAB	All	BA03
KIA	Carens 1999-	BA03	SUBARU	Coupe 1800 1988-	BA03
	Carens 2001-	BA05		Forester 1999-	BA03
	Carnival 1999-	BA05		Forester 2000-	BA03
	Carnival 2005-	BA03		Impreza 1,8GL	BA03
	Cerato 2005-	BA03		Impreza 4WD 1998-	BA03
	Clarus 1997-	BA05		Impreza WRX 2001-	BA03
	Joice	BA03		Justy 2003-	BA03
	Magentis 2001-	BA03		Legacy 1995-	BA03
	Opius 2003-	BA05		Legacy +Kombi 1999-	BA03
	Picanto 2005-	BA03		Outback 1989-	BA03
	Rio 2000-	BA07		Sedan 1800 4WD	BA03
	Rio 2003-	BA03	SUZUKI	Alto 1996-	BA05
	Pride 1995-	BA07		Samurei 1993-	BA05
	Sephia 1995-	BA05		Samurei Van 1989-	BA07
	Shuma 2000-	BA05		Samurei Van + Pick Up 1999-	BA05
	Sorento 2003-	BA05		SJ Samurei + SJ 413 1985-	BA07
	Sportage 1995-	BA05	TOYOTA	Avensis 1998-	BA05
LAMBORGHINI	All	BA05		4-Runner 1996-	BA10
LAND ROVER	All	BA05		Camry 1993-	BA10
LEXUS	All	BA10		Camry	BA11
MASERATI	3200 GT 1999-	BA05		Carina 1993	BA10
	Quattroporte 1999-	BA05		Celica 4WD	BA11
MAZDA	121 1995-	BA03		Celica GT 2,0 / GT 1600	BA11
	121 LX	BA07		Celica GT 2,0 / GT 1600 2001-	BA10
	2 2003-	BA05		Celica CS 2003-	BA10
	3 2003-	BA05		Corolla	BA11
	5 2005-	BA05		Corolla E11	BA10
	626 LX / GLX	BA07		Corolla 1993-	BA10
	6 2003-	BA04		Corolla 1996-	BA11
	B2500 PickUp 4WD 1998-	BA05		Corolla Combi 1972-1986	BA11
	B-Serie 2.5L TD 1999-	BA05		Corolla 2003-	BA05
	Demio 1998-	BA07		Cressida 1977-1981	BA05
	Luxus / LX + Sport	BA07		Crown 1985-	BA07
	MPV 1999-	BA03		Landeruiser	BA07
	MPV 2001-	BA04		Landeruiser HJ100	BA10
	MX-5 1999-	BA03		Landeruiser 2003-	BA10
	MX-5 2005-	BA05		MR-2 2003-	BA10
	Premacy	BA04		Previa	BA10
	RX-8 2003-	BA04		Prius 2001-	BA10
	Tribute 2001-	BA03		RAV 4 1996-	BA10
MERCEDES-BENZ	All	BA05		EAV-4 2003-	BA10
MINI	All	BA05		Starlet	BA11
MITSUBISHI	All	BA03		Tercel	BA11
NISSAN	100 NX 1993-	BA03	VOLVO	All	BA05
	200 NX 1993-	BA07	VOLKSWAGEN	All	BA05
	200 SX 1995-	BA03		Beetle 1998-2002	BA05
	200 SX - Turbo Maxima 3,0	BA07		Beetle 2003-	BA05
	350Z 2003-	BA03		Caddy 2005-	BA05
	Almera 1995-	BA03		EOS 2005-	BA05
	Maxima QX 1995-	BA03		Multivan 2003-	BA05
	Pathfinder + RS1 2005-	BA03		1500 Typ 1	BA07
	Patrol GR TD6 1999-	BA03		1500 / 1600 Typ 3	BA07
	Patrol Turbo D	BA07		411 / 412 Typ 2 (28 Durchm.)1988-	BA07
	Pick Up	BA07		LT 28	BA07
	Pick Up 2001-	BA03		Lupo	BA07
PONTIAC	Firebird + Cabrio	BA04		Sharan -2002	BA05
	Trans Sport	BA04		Sharan 2003-	BA05
PORSCHE	All	BA05		T4 1994-	BA05
RENAULT	All	BA05			